



Husky

Recommended Installation, Maintenance
and Inspection Instructions

X & 1A
EZL Nozzles

Conventional EZ Lever Nozzles

- ^1163403N ^1411303N ^1426404N 14531108 ^13458214N
- ^1163404N ^1426403N 11634124 14531109

SEE LISTING FOR DETAILS

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

WARNING Designed for use at motor fuel dispensing facilities only.

INSTALLATION INSTRUCTIONS

1. Turn off dispenser and relieve line pressure.
2. Use pipe thread sealant (not Teflon® tape) approved for gasoline on the male threads of hose section.
3. Tighten approximately 1 or 2 turns past hand tight - do not overtighten.
4. Pressurize system and visually check for leaks.
5. Test nozzle for proper automatic shut off between 5 - 10 gpm / 18.9 - 37.9 Lpm.

DO NOT OVERTIGHTEN. USE WRENCH ON HOSE NUT ONLY.

IF DRIVE OFF OCCURS

- Turn off dispenser and relieve line pressure.
- Visually check for fractured spout shear groove.
- Check for leaks.
- Check spout tip - should be in round and sensing port should be clear of debris.
- Perform flow test of nozzle automatic shut off between 5 - 10 gpm / 18.9 - 37.9 Lpm.
- Check for electrical conductivity.

TESTING / MAINTENANCE / INSPECTION

Daily



- Check for leaks / stains.
- Check for loose spouts.
- Check for damage.
- Check for bent lever.
- Check for broken clip / trigger spring.

Monthly



- Check nozzle automatic shut off between 5 - 10 gpm / 18.9 - 37.9 Lpm.
- Check "remove after" date.

Annually



- Check for electrical conductivity.
- Lubricate main valve stem.

- All drive aways, maintenance and inspection activities must be logged using the serial number of the individual product.
- Apply city, state, or federal testing regulations as appropriate.

ANY TEST / INSPECTION FAILURE REQUIRES IMMEDIATE EQUIPMENT REPLACEMENT OR REMOVAL FROM SERVICE.

MADE IN THE USA

**ALWAYS ADHERE TO INSTALLATION / USAGE INSTRUCTIONS AND WARNINGS.**

Improper use may result in injury, damage, or hazardous spill.

**GENERAL WARNINGS / INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSON:**

- Use of equipment is at individuals' own risk.



- Always place containers on the ground before filling.



- Always abide and adhere to city, state, and federal regulations regarding use and installation of dispensing equipment.



- Always discharge static electricity before using or servicing equipment by touching a metal part of the dispenser before and after fueling vehicle.



- Always follow the product manufacturer's installation and maintenance instructions.



- Never smoke within 20 ft / 6.1 m of dispensers.



- Always turn off all power to dispenser during maintenance and inspection activities.



- Never keep in service past recommended life.



- Always close the shear valves during maintenance and inspection activities.



- Never leave the nozzle unattended while dispensing fuel.



- Always relieve pressure from system prior to performing maintenance activities.



- Never use sparking or flaming devices within 20 ft / 6.1 m of dispensers.



- Always check continuity after installation using a megohmmeter (Refer to PEI RP 400 for details).



- Never use power tools near dispensers or to aid in the installation process.

- Always replace or remove from service damaged or leaking dispensing equipment immediately.



- Never use cell phone within 20 ft / 6.1 m of dispensers.

- Always report leaks / spills / accidents to appropriate authorities.



- Never reenter car when fueling vehicle.
- Never allow gasoline to touch eyes or skin.

- Always wear appropriate safety equipment during maintenance activities.

- Never use at flow rates in excess of regulatory guidelines.

- Always have appropriate fire extinguishing equipment within 5 ft / 1.5 m of dispensers.

- Never use at flow rates less than 5 gpm / 18.9 Lpm.

- Always use pipe sealant approved for gasoline service.

- Never dispense flammable material into unapproved containers.

- Never dispense fuel without a valid driver's license.

CAUTION: DO NOT TOP OFF!

Topping off can lead to spills and splashes.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION

WARRANTY

VAPOR PRODUCTS – Husky Corporation will, at its option, repair, replace, or credit the purchase price of any Husky® manufactured product which proves upon examination by Husky, to be defective in material and/or workmanship for a period of one (1) year of installation or fifteen (15) months from the manufacture date of shipment by Husky, whichever occurs first. The warranty period on repaired or replacement vapor recovery products is only for the remainder of the warranty period of the defective product.

CONVENTIONAL PRODUCTS – Husky Corporation will, at its option, repair, replace, or credit the purchase price of any Husky manufactured product which proves upon examination by Husky, to be defective in material and/or workmanship for a period of one (1) year from the manufacture date of shipment by Husky.

Buyer must return the products to Husky, transportation charges prepaid. This Warranty excludes the replaceable bellows, bellows spring assembly, spout assembly and scuff guard, unless (i) damage is obvious when the product is removed from shipping carton and (ii) the defective product is returned to Husky prior to use. This warranty does not apply to equipment or parts which have been installed improperly, damaged by misuse, improper operation or maintenance, or which are altered or repaired in any way.

The warranty provisions contained herein apply only to original purchasers who use the equipment for commercial or industrial purposes. There are no other warranties of merchantability, fitness for a particular purpose, or otherwise, and any other such warranties are hereby specifically disclaimed.

Husky assumes no liability for labor charges or other costs incurred by Buyer incidental to the service, adjustment, repair, return, removal or replacement of products. Husky assumes no liability for any incidental, consequential, or other damages under any warranty, express or implied, and all such liability is hereby expressly excluded.

Husky reserves the right to change or improve the design of any Husky fuel dispensing equipment without assuming any obligations to modify any fuel dispensing equipment previously manufactured.

OPERATION INSTRUCTIONS

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Activate dispenser. 2. Insert spout into fill pipe opening. 3. Lower hose end of nozzle so the spout spring catches the inside of the fill pipe. 4. Raise the lever and begin fueling. 5. Nozzle will shut off automatically when the tank is full. | <ol style="list-style-type: none"> 6. Wait 15 seconds to allow any fuel remaining in the spout to drain. 7. Remove nozzle from fill pipe by raising hose end of the nozzle. 8. Return nozzle to nozzle boot. <p><small>NOTE: Nozzle is equipped with a unique Flo-Stop® device that shuts off the nozzle if it falls from fill pipe or raises above horizontal.</small></p> |
|--|--|

FLO-EQUALIZER® INSTALLATION INSTRUCTIONS



Model 004490 Standard Flo-Equalizer®

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Turn off dispenser and relieve line pressure. 2. Install pipe nipple (if necessary) to achieve proper flow direction. 3. Use thread sealant on male threads -- DO NOT use Teflon tape. | <ol style="list-style-type: none"> 4. Tighten approximately ½ turn past hand tight - do not overtighten. 5. Confirm nozzle is properly installed, pressurize the system and check for leaks. <p><small>DISCLAIMER: In the event of pressure differential in excess of 25 psi / 1.7 bar across the Flo-Equalizer® or the presence of debris obstructing movement of internal components, the Flo-Equalizer® output may exceed 10 gpm / 37.9 Lpm.</small></p> |
|---|---|

TROUBLESHOOTING GUIDE

- | | |
|---|---|
| <p>Nozzle keeps shutting off or won't dispense...</p> | <ol style="list-style-type: none"> 1. Make sure dispenser is on and activated. 2. Slow down flow rate - use lower notch on clip. 3. Clean spout tip end. 4. Clean or replace filter. 5. Inspect Safe-T-Break®. 6. Replace spout assembly. 7. Check dispenser pressure - 19 psi / 1.3 bar to activate nozzle. |
| <p>Nozzle won't shut off...</p> | <ol style="list-style-type: none"> 1. Check flow rate - minimum of 3 gpm / 11.4 Lpm required. 2. Remove nozzle and drain hose. |
| <p>Nozzle leaks...</p> | <ol style="list-style-type: none"> 1. Check for loose spout. 2. Check hose connection. 3. Check for cracks in nozzle and hose threads. |
| <p>Low flow rate...</p> | <ol style="list-style-type: none"> 1. Remove Flo-Equalizer® (if equipped). 2. Verify dispenser is not in slow flow rate mode. 3. Check for system leak. |
| <p>Flow rate above 10 gpm / 37.9 Lpm...</p> | <ol style="list-style-type: none"> 1. Verify Flo-Equalizer® being used - either inside or outside dispenser. 2. Check Flo-Equalizer® for debris. |

GENERAL TECHNICAL DATA

Fuel Type	Test and warranty for gasoline and diesel fuel		
Flow Rate	X	Unleaded w/o Flo-Equalizer® = 14 gpm / 52.9 Lpm Light Duty Diesel w/o Flo-Equalizer® = 16 gpm / 60.5 Lpm	
	1A	Unleaded w/o Flo-Equalizer® = 20 gpm / 90.9 Lpm Light Duty Diesel w/o Flo-Equalizer® = 25 gpm / 94.6 Lpm	
Body	Die cast aluminum		
Disc	Fluorocarbon		
Packing	Double O-ring seal protected by fiber reinforced Teflon®		
Lever	X	Two piece polymer	
	1A	Two piece stamped steel construction with high impact polymer cover	
Shipping Weight	X	Unleaded = 3 lbs / 1.3 kg	Light Duty Diesel = 3.1 lbs / 1.4 kg
	1A	Unleaded = 3.3 lbs / 1.4 kg	Light Duty Diesel = 3.4 lbs / 1.5 kg
Threads	X	¾" / 19.1 mm NPT	
	1A	1" / 25.4 mm NPT	
Spout	Unleaded = 13/16 in / 20.6 mm O.D.		Light Duty Diesel = 15/16 in / 23.8 mm O.D.
Case Quantity	15		
Listings	Default		+ 
			^ Not Listed

SPOUT REPLACEMENT INSTRUCTIONS

Model 001471 Light Duty Diesel Spout,
001473 Unlead Spout

1. Remove spout lock nut and spout.
2. Remove and discard spout seal.
3. Place new spout seal in groove.

4. Insert new spout into body making sure the vent tube is in the port.

5. While holding the spout in proper alignment, tighten spout lock nut firmly, approximately 35 - 60 lb•ft / 47 - 81 N•m. Do not overtighten.

HOLD OPEN CLIP INSTRUCTIONS

Model 003593 Hold Open Clip Kit

INSTALLATION

1. Remove nozzle from hose and drain.
2. Position latch spring under latch clip and hose them in place. The latch clip should straddle the mating holes in the trigger lever.
3. Insert latch rivet through latch clip and lever, making sure latch spring is secured in position by the rivet.
4. Install push nut on rivet - DO NOT hammer in place.
5. Squeeze lever several times to check operation.
6. Verify clip and lever are parallel.

NOTE: Field installation of the hold open clip is NOT UL approved because improper installation may cause the nozzle to fail.

REMOVAL

1. Remove nozzle from hose and drain.
2. Place nozzle on a flat surface in safe location.
3. Hold up on the latch clip to prevent rivet from rotating.
4. Drill off the riveted end using a ¼ in / 6.4 mm bit.
5. Remove clip, rivet and torsion clip spring.
6. Do not remove latch plate.

NOTE: Nozzles can be ordered without clips.

GUARD REPLACEMENT INSTRUCTIONS

NOZZLE GUARD

Model 004145, 000554

1. Turn off dispenser and relieve line pressure.
2. Remove nozzle from hose.
3. Remove waffle splash guard (if applicable).
4. Remove old nozzle guard.
5. Install new nozzle guard over spout and pull back to cover nozzle body.
6. Re-install nozzle to hose.
7. Re-install waffle splash guard (if applicable).
8. Test nozzle for automatic shut off.

NOZZLE REGUARD

Model 001804, 001806

1. Remove waffle splash guard (if applicable).
2. Cut old guard at nozzle inlet and remove from nozzle.
3. Install new nozzle reguard over spout and pull back to cover nozzle body.
4. Pull zip tie through the eyelets and loop under nozzle inlet.
5. Pull tightly and trim off excess tie.
6. Re-install waffle splash guard (if applicable).

REGUARD PACKAGE

Model 001809, 001811

1. Remove old waffle splash guard.
2. Cut old nozzle guard at nozzle inlet and remove from nozzle.
3. Install new nozzle guard over spout and pull back to cover nozzle body.
4. Pull tie through the eyelets and loop under nozzle inlet.
5. Pull tightly and trim off excess tie.
6. Install new waffle splash guard over spout lock nut.

WAFFLE SPLASH GUARD

Model 001807, 001808

1. Remove old waffle splash guard.
2. Install new waffle splash guard over spout lock nut.

LEVER COVER

Model 005494

1. Remove old lever cover.
2. Snap new lever cover into place.

PROTECTION PACKAGE

Model 000099, 001506

1. Turn off dispenser and relieve line pressure.
2. Remove nozzle from hose.
3. Remove old waffle splash guard (if applicable).
4. Remove old nozzle guard.
5. Install new nozzle guard over spout and pull back to cover nozzle body.
6. Install new waffle splash guard over spout lock nut.
7. Re-install nozzle to hose.
8. Test nozzle for automatic shut off.

POPD® CLEAR COVER

Model 006628

1. Trim advertisement to 3.75 in / 95.25 mm x 3.75 in / 95.25 mm.
2. Notch corners of advertisement approximately .375 in / 9.5 mm x .375 in / 9.5 mm.
3. Turn clear cover "inside out".
4. Center advertisement on POPD® guard, using the notched corners as guides, and fold over the edges.
5. Lay clear cover over advertisement, making sure the advertisement stays centered, and turn it "right side out".
6. Confirm the cover is securely in place.

POPD® GUARD

Model 006665, 006655

1. Turn off dispenser and relieve line pressure.
2. Remove nozzle from hose.
3. Remove waffle splash guard (if applicable).
4. Remove old nozzle guard.
5. Install new POPD® guard over spout and pull back to cover nozzle body.
6. Re-install nozzle to hose.
7. Re-install waffle splash guard (if applicable) over spout lock nut.
8. Test nozzle for automatic shut off.
9. Install desired advertisement and clear cover (model 006628).

POPD® REGUARD

Model 007205, 007210

1. Remove waffle splash guard (if applicable).
2. Cut old guard at nozzle inlet and remove from nozzle.
3. Install new POPD® reguard over spout and pull back to cover nozzle body.
4. Pull zip tie through the eyelets and loop under nozzle inlet.
5. Pull tightly and trim off excess tie.
6. Re-install waffle splash guard (if applicable).
7. Install desired advertisement and clear cover (model 006628).

ACCESSORIES

Model 000385 Reducer Bushing (1" / 25.4 mm to ¾" / 19.1 mm)

Model 000397 Unleaded spout gauge