


# 17717SS

FLASHED SPLIT TOP L-FOOT  
FOR ASPHALT SHINGLE ROOFS



A DIVISION OF QUICKSCREWS INTERNATIONAL CORP

# INSTALL INSTRUCTIONS



## RECOMMENDED MATERIALS

- Rafter locator
- Chalk or a crayon
- Drill with a 1/4" drill bit
- MFG approved sealant
- 1/2" Nut Setter
- Bar

## INSTALLATION INSTRUCTIONS

1. Locate the and mark the rafter
2. Predrill the hole
3. Fill the predrilled hole with MFG approved sealant
4. Drive the Screw until the L-Foot is secure
5. Lift the shingles and place selaant around the L-Foot
6. Insert the Flashing underneath the shingles

