



EN

# BRAINZ 2-IN-1 EARBUDS & SPEAKER INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY  
AND KEEP THEM FOR LATER REFERENCE



## What you need

- USB cable (included)
- Mobile phone, tablet, or laptop with Bluetooth (not included)

## How to Charge the 2-in-1 Earbuds & Speaker

Connect the provided cable to the speaker and plug the USB end into a power source. The speaker will charge when the blue lights at the bottom blink. The number of blue lights will indicate the battery level. The earbuds will charge in the speaker case.

## How to Set Up the 2-in-1 Earbuds & Speaker

Ensure that the device is fully charged before using it. Turn on the 2-in-1 Earbuds & Speaker by holding the button at the bottom of the speaker for 3 seconds. The 2-in-1 Earbuds & Speaker will appear as 'BRAINZ S70' in the new Bluetooth connections on your device. Click on it to establish a connection, and the device will be ready to use. To connect the earbuds, remove them from the case. The earbuds will appear in your Bluetooth connections as 'BRAINZ H70.'

## Volume

To adjust the speaker's volume, use the device connected to the 2-in-1 Earbuds & Speaker. When using the earbuds, you can decrease the volume by double-tapping on the back of the left earbud. To increase the volume, double-tap the right earbud. Repeat this to further increase or decrease the volume.

## Pause music

Press the button at the bottom of the 2-in-1 Earbuds & Speaker once to pause the music from the speaker. Repeat this to resume the music. When using the earbuds, you can pause the music by tapping the back of the earbud. Repeat this to resume the music. This can be done with both the left and right earbuds.

## Voice Control

Touch and hold the back of the earbuds with your finger to activate voice control. This can be done with both the left and right earbuds.

## Turning Off the Earbuds

To turn off the earbuds, place them back in the 2-in-1 earbuds & speaker case. Bluetooth will automatically switch to the speaker. Hold the button at the bottom of the speaker for 3 seconds to turn off the speaker.

## Turning Off the Speaker

To turn off the speaker, hold the button at the bottom of the speaker for 3 seconds.

## Note:

Do not use a charger with a higher voltage than what is suitable for this product.

This manual is valid for article number 38577.

For more information about this product, please visit [www.brainz-electronics.nl](http://www.brainz-electronics.nl)



NL

# BRAINZ 2-IN-1 EARBUDS & SPEAKER GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN  
EN TE BEWAREN VOOR LATER GEBRUIK



## Dit heeft u nodig

- USB Kabel (inbegrepen)
- Mobiele telefoon, tablet of laptop met Bluetooth (niet inbegrepen)

## Zo laadt u de 2-in-1 Earbuds & Speaker op

Verbind de meegeleverde kabel aan de speaker en verbind de USB-zijde aan een voedingsbron. De speaker laadt op als de blauwe lampjes aan de onderkant knipperen. Aan de hoeveelheid blauwe lampjes is te zien hoe vol de batterij is. De earbuds laden op in de speakercase.

## Zo stelt u de 2-in-1 Earbuds & Speaker in

Zorg ervoor dat het apparaat volledig is opgeladen voordat u deze gebruikt. Zet de 2-in-1 Earbuds & Speaker aan door de knop aan de onderkant van de speaker voor 3 seconde vast te houden. De 2-in-1 Earbuds & Speaker zal onder de nieuwe Bluetooth connecties op uw apparaat verschijnen als 'BRAINZ S70'. Door hierop te klikken maakt uw telefoon verbinding en is het apparaat klaar voor gebruik. Om de earbuds te verbinden haalt u deze uit de case. De earbuds zullen in uw Bluetooth connecties verschijnen als 'BRAINZ H70'.

## Volume

Om het volume van de speaker aan te passen gebruikt u het apparaat waarmee de 2-in-1 Earbuds & Speaker verbonden is. Wanneer de earbuds gebruikt worden kan het volume verlaagd worden door dubbel te tikken op de achterkant van de linker earbud. Om het volume te verhogen klikt u dubbel op de rechter earbud. Herhaal dit om het volume verder te verhogen of te verlagen.

## Muziek pauzeren

Druk 1 keer op de knop aan de onderkant van de 2-in-1 Earbuds & Speaker om de muziek van de speaker te pauzeren. Herhaal dit om de muziek te hervatten. Wanneer u de earbuds gebruikt kan de muziek gepauzeerd worden door te tikken op de achterkant van de earbud. Herhaal dit om de muziek te hervatten. Dit kan zowel met de linker als de rechter earbud.

## Stembediening

Raak de achterkant van de earbuds aan met uw vinger en houdt deze vast om stembediening te activeren. Dit kan zowel met de linker als de rechter earbud.

## Uitzetten van de earbuds

Om de earbuds uit te zetten doet u deze terug in het doosje van de de 2-in-1 earbuds & speaker. De bluetooth zal automatisch overgaan naar de speaker. Houd de knop aan de onderkant van de speaker 3 seconden ingedrukt om de speaker uit te zetten

## Uitzetten van de speaker

Om de speaker uit te zetten houdt u de knop aan de onderkant van de speaker voor 3 seconde ingedrukt.

## Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.

Deze handleiding is van toepassing op artikelnummer 38577  
Meer informatie over dit product vindt u op [www.brainz-electronics.nl](http://www.brainz-electronics.nl)