



- To see details of specifications and operations, refer to the instruction manual:  051x instruction manual

## Component identification



- Actual appearance may differ from the illustration.
- The crown has two positions when pulling it out.
- Refer also to our web page for detail of usage of the scale and bezel on the watch. (<http://www.citizenwatch-global.com/support/pdf/enhanced/e.pdf>)

## Setting the time

- Pull the crown out to position 2 when the small second hand points 0 second.**
- Rotate the crown to set the time.**
  - Move the hands 4 or 5 minutes forward and move them back to the right time to set the time more precisely.
  - Change of date indication shows it just became AM. Take care the time set is AM or PM.
- Push the crown in to position 0 in accordance with a reliable time source to finish the procedure.**  
The small second hand starts moving.

## Setting the date indication

- Do not adjust the date indication while the watch shows 9:00 PM - 1:00 AM. Otherwise, the date indication may change incorrectly thereafter.
- Date indication adjustment is required on the first days of March, May, July, October and December.

- Pull the crown out to position 1.**
- Rotate the crown to adjust the date indication.**
- Push the crown in to position 0 to finish the procedure.**

## Using the chronograph

- Measuring up to 12 hours in 1 second increments.

- Push the crown in to position 0.**
- Press and release the button B.**  
The chronograph starts moving.

**Start/stop:** press button B.

**Reset:** press button A while the chronograph is stopped.

- Be sure to reset chronograph after finishing measurement.

## Adjusting the 0 position of the chronograph hands

Follow the steps below when the chronograph hands (chronograph hour/minute/second hands) do not return to the 0 position even after resetting the chronograph.

- Pull the crown out to position 2.**
- Press and release the button B repeatedly to adjust the chronograph second hand to the 0 position (12 o'clock position).**
  - Pressing and holding the button moves the hand continuously.
- Press and release the button A.**  
The chronograph minute and hour hands return to the 0 position.
- Set the time and push the crown in to position 0.**