

Festive

Assembly and Usage Instructions for P058157 120cm Waving Reindeer on Tree

Box Contents:

1 x Infinity light 1x mounting base 1 x Transformer with inline timer function 1 x Pack of outdoor fittings.

Assembly instructions.

Remove the Infinity light out of the packaging, taking care not to damage the item.

1. Remove the protective film covering the Infinity light from both sides.
2. Due to product construction, the foam is compressible so You can squeeze the mirrors together at one end / corner (it will not damage) and put the one compressed corner into the base on an angle.
3. Slide the Infinity light fully onto the base. It is very important to make sure the holes in the infinity light and the base are in the same line so required bolts can be fitted.
4. To complete the assembly please follow the separate outdoor instructions provided with this product.

How to operate:

Plug the transformer into the wall socket and switch on at the socket, the light will come on.

To turn the lights off, switch off at the wall socket.

The transformer must be always kept indoor!!

This item is supplied with an inline timer switch.

To Turn the timer on, press the clear button once.

The green light will indicate that the timer function is on

The lights will stay LIT for 8 hours and then switch itself off
and remain off for next 16 hours

To switch the timer off, press the clear button once.

This will also switch the Infinity light off.

Removing the inline switch would not have any negative effect on the Infinity product.

The lights will be always LIT.



Care:

Check fittings regularly to make sure they are tight.

Check outdoor fixing cables regularly to make sure they are taut to prevent the item from tipping over.

Remove base and store flat when not in use.

Clean with a dry, clean cloth

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com

Festive

Warnings:

It is very important that this product is NEVER DIRECTLY connected to the mains supply without the supplied transformer.

Keep away from children & pets.

Do not operate this item whilst still in the packaging.

The LED lamps are not replaceable.

The transformer is only suitable for indoor use only.

Do not try to connect this set electrically to another set.

If there is any damage or breakage to the electric wire, please dispose of safely.

Ensure that cables are fully unwound and sited where they will not become damaged or present a tripping hazard.

Do not secure the wiring of this product with staples or nails.

Do not close doors or windows on the product, as this may damage the wiring insulation.

Do not overload wall sockets. Use different sockets around the house to plug in multiple lights to balance the load. Do not damage the insulation of cable or LED holder.

Do not lay the cable under carpet or where it can be damaged.

For indoor and outdoor use.

Electrical ratings:

Input 230-240V ~ 50HZ

This set operates on- 10.8V DC 23.4W

Transformer rating- 12V DC 36W

Led Bulb rating- 3v 0.067a 0.2w



This Symbol indicates that this product is covered by legislation for waste electrical electronic products. When the product has reached the end of its life, please do not dispose of it with general household waste. Consider the environment and take it to a recognised recycling facility.

UK
CA

CE



TRANSFORMER



LIGHTSET

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com