

Contents

- 1 Front Cover
- 2 Safety Instructions
- 3 Operating Instructions
- 4 Back Cover



2000W Double Hot Plate

Contents

- 1 Front Cover
- 2 Safety Instructions
- 3 Operating Instructions
- 4 Back Cover

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.


- Never carry out any alterations or modifications to this product.
- This product is not a toy, and is only to be used for its designated purpose.
- This product is intended for indoor use only.
- Only use this product on stable, level and dry surfaces.
- Never leave the appliance unattended when in use.
- The top crystallite surfaces and the heating elements become extremely hot and can cause severe burns. Do not touch these parts whilst they are hot.
- Make sure the appliance doesn't come into contact with outside sources of heat, such as a cooker top or an open flame.
- To protect against electrical shock, do not immerse cord, plug or any part of this appliance in water or any other liquid.
- Ensure the power supply to the socket into which the appliance is plugged, is in accordance with the rating label on the appliance, and that the socket is earthed.
- When the appliance is not in use, always unplug from the mains socket.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials, as these may damage the product.
- Make sure the product is off, unplugged from the socket and has been left for five minutes to remove the risk of electrical shock.
- Do not use pans that are unstable and/or easily tipped. Use flat-bottomed pans to ensure full contact with the hotplate for maximum heat efficiency.
- For long-life performance, avoid dropping any items onto the infrared hotplate.
- When using this infrared hotplate for the first time, you may encounter some smoke due to the manufacturing oils used during production. This is perfectly safe and normal.
- Do not use glass containers to cook using this appliance.
- If the product is damaged or has any defects, please contact our customer services team at cservice@oypla.com

Contents

- 1 Front Cover
- 2 Safety Instructions
- 3 Operating Instructions
- 4 Back Cover

Operating Instructions

Appliance Diagram



Usage Instructions

- Before using your infrared hot plate for the first time, turn the hot plate to the highest setting (position 5) for 3 to 5 minutes to protect the coating. This should be done when there is no cooking utensil on the hot plate.
- 1) Put the hot infrared hotplate on a flat, dry and heat resistant surface.
 - 2) Turn the temperature control dial to off.
 - 3) Insert the plug into the power socket.
 - 4) Turn the control dial to the desired setting. The unit will cycle on and off to maintain the selected temperature.
 - 5) The indication light at the front of the appliance will turn off when the hot plate reaches the desired temperature, and the procedure of the heating will stop and recycle to maintain the temperature.
 - 6) The heating element will begin to heat immediately. Do not touch whilst in use, the housing surface will be hot.
 - 7) When not in use, unplug the power cord from the wall outlet and allow it to cool down completely.

Contents

- 1 Front Cover
- 2 Safety Instructions
- 3 Operating Instructions
- 4 Back Cover

To keep food warmer

- 1) Turn the temperature knob to “2” to maintain food at a constant warm temperature.
- 2) Turn the knob off and food will stay warm for up to 30 minutes as the hot plate gradually cools down.

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



OYPLA.COM

An Official OYPLA Branded Product



Environmental Protection

Products bearing the symbol shown below means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



Imported by Oypla.com LLP, Uxbridge, UB8 2FX

Manual Version: **V1.0**

Model Code: **3838**

Oypla.com LLP / www.oypla.com