



## Safety, Warnings and Warranty

***Read The Quick Start Guide  
Before Product Use***

## **⚠ WARNING**

# **SAFETY AND HANDLING**

## **1. Handling**

Handle your Omnicharge with care. Set up your Omnicharge on a hard, stable work surface which allows for adequate air ventilation around the power bank. Omnicharge can be damaged if dropped, burned, punctured, crushed, exposed to heat or moisture or if it comes in contact with liquid. Do not use a damaged Omnicharge as it may cause injury.

---

## **2. Small Children**

This is not a children's product and is not intended for use by children under 14 years old. It can generate the same potentially dangerous level of AC power as in a normal household wall outlet.

---

## **3. AC Outlet ( only available for product with AC port )**

Be cautious when inserting a plug into the AC outlet. Do not insert foreign objects into the AC outlet. Keep your fingers clear of the AC outlet. Consult with your device manufacturer to check whether your device is compatible with Omnicharge's modified sine wave AC and/or HVDC.

---

## **4. Prolonged Heat Exposure**

Omnicharge and its power supply may become very warm during peak usage. Sustained contact with warm surfaces for long periods of time may cause injury or damage. Avoid situations where your skin is in prolonged contact with Omnicharge or its power supply when it is operating or plugged into a power source. Do not operate your Omnicharge on a pillow, blanket or other soft material that can block ventilation openings. Never push anything into the ventilation openings, as doing so may be dangerous and cause your power bank to overheat. If your Omnicharge gets uncomfortably warm, power off and place it on a stable, well-ventilated work surface. Take special care if you have a physical condition that affects your ability to detect heat against the body.

## **⚠ WARNING**

### **5. Medical Device Interference**

Omnicharge contains components that emit electromagnetic fields, which may interfere with pacemakers, defibrillators or other medical devices. Maintain a safe distance between your medical device and Omnicharge. Consult your physician and medical device manufacturer for specific information. If you suspect Omnicharge is interfering with your medical device, stop using Omnicharge at once.

---

### **6. Battery**

Do not attempt to replace or modify the Omnicharge battery yourself - you may damage the battery, which could cause overheating, fire and injury. Improperly replaced batteries may present a risk of leakage, explosion and personal injury.

Mistreated rechargeable batteries may present a risk of fire or chemical burn. Do not disassemble or expose to conducting materials, moisture, liquid or heat. Do not use or charge the battery if it appears to be leaking, discoloured, deformed or in any way abnormal. Do not leave your battery discharged or unused for extended periods. Do not short circuits. Battery life varies with usage.

The battery in your device should be serviced or recycled by an authorized service provider, and must be recycled or disposed of separately from household waste. Dispose of batteries according to your local environmental laws and guidelines. If no laws or regulations govern, dispose of your device in a waste bin for electronics. Keep the battery away from children.



**Li-ion**



**Li-ion**

---

### **7. AC Wall Charger**

The power supply is for indoor use only. Do not attempt to repair or use a damaged power supply. Do not immerse the power supply in water or subject it to physical abuse. Inspect the power supply regularly for cable, plug and casing damage.

## **NOTICE**

### 1. Adjustable DC Output (Only available for product with DC port)

Improper use of DC output may harm your device. Consult with your device manufacturer to check the designated voltage before using adjustable DC output.

---

### 2. Repairing

Your Omnicharge is not user serviceable. Do not open or disassemble Omnicharge or attempt to repair it or replace any components. Disassembling Omnicharge may damage it and/or may cause injury to you. If Omnicharge needs service, is damaged, malfunctioned or comes in contact with liquid, stop usage and contact Omnicharge at support@omnicharge.co. If you attempt to open it, you risk damaging your Omnicharge, and such damage is not covered by the limited warranty for your Omnicharge.

---

### 3. Carrying your Omnicharge

If you carry your Omnicharge in a bag or briefcase, make sure there are no loose objects that could accidentally get inside the Omnicharge ventilation openings or get stuck inside a port.

---

### 4. Storing your Omnicharge

If you are going to store your Omnicharge for an extended period, keep it in a cool location(ideally 71°F or 22°C) and fully charge the battery. When storing your Omnicharge for an extend period, maintain the capacity of the battery by charging the battery to 100 percent every six months.

## **NOTICE**

This product is meant for use only in conjunction with appropriate devices. Please consult your device packaging to determine whether this product is compatible with your particular device. The manufacturer is not responsible for any damages to any device incurred through the use of this product.

The manufacturer shall not in any way be liable to you or to any third party for any damages you or any third party may suffer as a result of use, intended or unintended, or misuse of this product in conjunction with any device or accessory other than the appropriate device for which this product is designed.

The manufacturer shall not be responsible for any damages you or any third party may suffer as a result of misuse of this product as outlined above.

You are responsible for product use with an unintended device and any damages resulting from such use. You agree to indemnify the manufacturer for any resulting injuries to any third party(ies).

---

## **OMNICHARGE ONE-YEAR LIMITED MANUFACTURER'S WARRANTY**

Omnicharge warrants that its hardware product shall be free from defects in materials and workmanship for the length of time identified on your product packaging beginning from the date of original retail purchase. Omnicharge does not warrant against normal wear and tear, nor damage caused by accident or abuse.

See [www.omnicharge.co](http://www.omnicharge.co) for specific warranty information about your product and procedures to act on a warranty claim. Omnicharge's entire liability and your exclusive remedy for any breach of warranty shall be, at Omnicharge's option, to repair or replace a functional equivalent of the product. You may be required to furnish proof of purchase details when making a claim under this warranty. Warranty protections are in addition to rights provided under local consumer laws and may vary among countries, states and provinces. See the full warranty information to know your consumer rights and the additional protections provided by this product warranty.

[www.omnicharge.co/warranty](http://www.omnicharge.co/warranty)

## **IC, FCC AND EU COMPLIANCE STATEMENT**

This device complies with part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi même si le brouillage est susceptible d'en compromettre le fonctionnement.

Omnicharge Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the EMC and LVD Directive.



Important: This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components.

It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference of radios, televisions and other electronic devices.

∴.omnicharge™



<https://www.facebook.com/omnicharge>



<https://www.instagram.com/omnicharge>



<https://www.youtube.com/c/omnicharge>



[https://twitter.com/omni\\_charge](https://twitter.com/omni_charge)

---

© 2017 Omnicharge.

∴.omnicharge is a trademark of Omnicharge Inc.

Nothing in this Disclaimer shall be construed to confer any rights upon Consumer by implication, estoppel, or otherwise as to any intellectual property rights of Omnicharge.

v.1.00