

DELLA™ ICE MAKER

Instruction Manual
item no. 048-GM-48227



Thank you for purchasing our product
Make sure you have read manual before using, properly use
the appliance in accordance with the instructions.
Please well keep this instruction manual



www.dellaproductsusa.com
(949)344-2588

Make sure you have read and understand this manual before using the appliance and follow all instructions.

Please retain this instruction manual for future reference.

Basic Introduction

The Ice maker is a product used to make ice cubes. With a modern design, Hygienic internal skin, it is suitable for everyday use. The automatic ice-making system works quickly and produces ice cubes in a standard size. Three different size modes can be selected according to your requirements.

In order to keep the ice maker working efficiently and smoothly, please always follow our instructions.

I. Product Features

- Using compressor technology, the ice maker produces ice cubes efficiently.
- This appliance is intended to be used in the home and similar applications such as:
 - Kitchen areas in shops, offices and other working environments;
 - Bars;
 - Hotels, motels and other residential type environments;
- The Ice making process can be viewed through the transparent window.
- Push-button operation.
- LCD indicators - lights indicate the various functions.
- Low water warning and warning for full storage box – remove ice to continue process

2/7

ON/OFF button for more than 5 seconds to release self-cleaning mode to change for other operations.

X. Cleaning

- Make sure to unplug the appliance before cleaning and long time off use.
- Use a damp cloth to clean both the interior and exterior of the appliance.
- Water tank cleaning.
 - Unscrew the nut of water outlet, drain off the water.
 - Pour clean water into the water tank, use a clean cloth to wipe water tank around. Pour clean water again until the flowing out water is clean, and then drain off water and grip the nut.
 - Do not use organic solvents, boiling water, cleaning agents, strong acids, strong acid and Alkali etc substances for cleaning.
- If ice machine will be off use for a long time, you should unplug the appliance, drain out the water and dry the appliance with a clean cloth, store the ice maker in a clean place.

XI. Technical Parameters

Model no.:	048-GM-48227
Power supply	110V~ 60Hz
Refrigerant	0.9A
Climatic class	SN/N/ST
Ice making capacity	12kg
Max ice storage	0.8kg
Max water storage	2.2kg
Clock function	Yes
Time setting	Yes
Filling water alarm	Yes
Ice full alarm	Yes
Functions Achieve	Button
Display mode	LCD
Outer sizes	249×360×327mm
Net weight	11.5kg

7/7

		2. Internal components are damaged. Maintenance Required – seek professional help
Low Water indicator flashes	Absence of water	1. Fill water compartment with clean water, push the key to eliminate the failure. 2. water supply system or components damaged, send to professional service centre for repairs
Ice making performance is not good.	1. Check ventilation outlets. 2. Water temperature is too high. 3. Ambient temperature is too high. 4. Refrigerant leak.	1. Clean the dust on the cooling fan and air inlet/outlet. 2. Fill room temperature water. 3. Do not place the appliance in high temperature conditions. 4. Refrigerating system is damaged. Maintenance Required – seek professional help
Abnormal noise	Fan or pump is damaged.	1. Move appliance to a flat suitable location. 2. Maintenance Required – seek professional help

IX. Self-Clean Mode Operating Instructions:

The self-clean mode should be put into operation before you use your ice maker for the first time and/or if there has been a long period without use.


Three icons as Large, Medium and small icons will be on at the same time when the ice maker is in self-clean mode.

Stage 1

- Add equal parts of water and vinegar (1:1) to the ice maker's reservoir.
- With the stand-by mode, hold the ON/OFF button at least 5 seconds to activate the self-clean mode. Please note that self-clean mode will start automatically after "Beep" sound.
- During the self clean mode, the upper water bucket is filled and dumped. The pump will remain in continuous operation as it feeds water to the bucket and evaporator coils. This cycle will continuous for five times.
- Upon completion, the unit automatically changes to stand-by mode.

Stage 2


- Drain the cleaning solution from the internal reservoir by removing the rear drain cap and plug.
- Add fresh water to the Max. permit water volume line.
- With the stand-by mode, keep pressing ON/OFF button at least 5 seconds to activate the self-clean mode again which will now act as a rinse.
- Upon completion of this final stage of the self clean process, the unit automatically changes to stand-by mode. Proceed to drain the water from the internal reservoir by removing the rear drain cap and plug. Leave the lid on the ice maker open to allow it to air dry.

Please note if there is a water shortage during Self-cleaning mode, the unit will automatically go into stand-by mode; If water bucket is fail to turn over,  icon will be on, you need to hold

6/7

II. Components' List:

Transparent window
Cover
Operation panel
Air outlet
Air inlet
Power cord
Water outlet
Ice storage box
Evaporator
Ice making box



III. Safety precautions

- Check that the mains voltage corresponds to the rating of the appliance before operating.
- Use handles when moving.
- Place on a flat stable surface for use.
- Do not use outdoors.
- Do not use near or in the immediate vicinity of a bath or swimming pool or any source of liquid.
- Unplug from socket outlet when not in use.
- To protect against electric shock, do not immerse cord or plug in water or any other liquid
- Do not locate this appliance immediately above a socket outlet.
- Do not allow cord to overhang the counter top where it can be tripped on.
- Do not use this appliance for anything else other than its intended use.
- Do not overfill as this may cause a hazard. Do not fill above the MAX or below MIN mark.
- Ensure lid is closed when in operation.
- To remove plug from outlet, do not pull on power cord. Grasp plug firmly and pull to remove.
- No liability can be accepted for any damage caused by non compliance with these instructions or any other improper use or mishandling.
- This appliance is for household use only.
- This appliance is not intended to be operated by means of an external timer or separate remote control system.

3/7

- If the power cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please follow local regulations regarding disposal of the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- WARNING: fill with drinkable water only.


IV. Environment Limitations

- Keep away from heating sources and avoid direct sunlight so as not to impact the ice-making process.
- Ice maker should be situated in a well ventilated area. Ensure there is a minimum space of 20cm around the machine so not to obstruct air inlets and outlets.
- Ambient temperature for Ice maker must not be less than 5°C.







V. Before using the Icemaker

- Remove all the package components.
- Ensure all accessories correspond to that of the instructions.
- Pour water into the water tank - use normal drinking water for making ice.
- Clean the machine and its components before use.




VI. Using your Icemaker

- Plug into power source.
- Do not turn on the Ice maker within 30 minutes of moving the machine.
- Pour water into the water tank - use normal drinking water for making ice.
- Press  key to start making ice.

VII. Operation Panel.

Buttons and Icon	Functions
 Button	Making Ice, Standby, Eliminating faults.
SELECT Button	Selecting Ice cube size: L, M, S three sizes.
▲ key	Power on or off time setting; power on and off time setting; three states setting switch
SET key	Clock-time setting, power off time setting, power on and off time setting switch
 Icon	Ice dropping fault indication, trouble-free flashing
 Icon	Water absence fault indication, fault-free flashing
 Icon	Large, medium, small size ice size instructions, the default Medium.
 Icon	Ice full instruction.
 Icon	Real-time indicator icon

4/7

 Icon	Power on time setting function indicator
 Icon	Clock icon indicates real time(24 hour system), set real time, regular time, in hours and minutes respectively blinking, no time setting display real-time, the default time display 12:00
 Icon	Ice display status indicator, flashing while ice making time, still while standby.



- Real Time Setting: Press the SET button one time, **88** hour blinking, press the ▲ button to set hour, press the SET button once, **88** minutes flash, press the ▲ button to set minutes.
- The timer for the machine start on time setting: press the SET button 3 times, **88** hour blinking, press the ▲ button to set hour, press the SET button once, **88** minutes flash, press the ▲ button to set minutes;
- Set the machine power off time: Press the SET button 5 times, **88** hour blinking, press the ▲ button to set hour, press the SET button once, **88** minutes flash, press the ▲ button to set minutes;
- The timer functions turn on use: Press ▲ to set timer, set the cycle timer function mode: power on → time power off → time off power on and off, power on default time is 8:00, power off default time is 12:00.

VIII. Troubleshooting

Faults	Reason	Treatment
Power indicator is not lit.	Switched on is not powered on.	1. Check the power supply matches 2. Check the power cord is connected correctly 3. Internal components are damaged. Maintenance Required – seek professional help.
ICE FULL indicator is lit.	1. Ice box full. 2. Low-temperature protection(temperature is lower than 5°C.).	1. Remove Ice cubes. 2. Move the Ice maker to a warmer place, where the ambient temperature is higher than 5°C.
Malfunction indicator light flashes	Ice making box reset in bad condition	1. Check whether any foreign body obstructing the ice making box.

5/7